


TP-Link Deco - X58-4G Set Up Instructions


1. Download the TP-Link Deco app

- When you open the box the first step will tell you to download the TP-Link Deco app (please note, at this stage you should NOT power on the Deco unit).
- You should use your preferred/regular mobile phone or tablet to download the TP-Link Deco App from either the Google Play or Apple App stores.
- Once installed, the Deco app will appear on your device as 'Deco'. Open the app to begin the set-up process.

Apple App Store - IOS



Google Play - Android



2. Log into the Deco App

- When you first open the app you'll be met with a login screen. If you're a new user, you'll need to create a TP Link username and password via the Sign Up button.
- It's recommended you use your preferred email address and a password that you can remember in case you ever need to reinstall the app.

Welcome to Deco

Email address

Password

[SIGN UP](#)

[FORGOT PASSWORD?](#)

[LOG IN](#)

3. After logging in tap "Let's Begin"




Paint Your Home in Wi-Fi




[LET'S BEGIN.](#)

[LOG OUT](#)


4. Identify your Deco by tapping the X58-4G



5. Tap on 4G/5G



6. Tap on next




What you'll need

Get these items ready before you start. You'll only need one Deco for now. More can be set up later.

NEXT

Note: There may already be a SIM card inserted into your Deco from your service provider.

7. Insert the SIM card into the Deco if you haven't done so already, then tap on Next



Insert the SIM Card


Push the SIM card into the slot until you hear a click.

Do not connect your Deco to a router/modem/Ethernet outlet during the setup.

Next

Note: If there's already a SIM card inserted, skip this step.

8. Position the Deco X58-4G near a window and power outlet, then tap on Next




Position your Deco

Place your Deco in an open area near a window and power outlet. Look for a location where it can receive a strong 4G signal. For best signal try windows on different sides of the house.

Next

9. Swiping the picture on the app will show where you shouldn't position the Deco X58-4G




Position your Deco

Place your Deco in an open area near a window and power outlet. Look for a location where it can receive a strong 4G signal. For best signal try windows on different sides of the house.

Next

9. continued - Swiping the picture on the app will show where you shouldn't position the Deco X58-4G




Position your Deco

Place your Deco in an open area near a window and power outlet. Look for a location where it can receive a strong 4G signal. For best signal try windows on different sides of the house.

Next

10. Power on the Deco and wait until the LED light pulses blue, then tap on "DECO'S LED IS PULSING BLUE"




Power on Deco and wait until the LED pulses blue

- Solid Yellow: Deco is starting up, please wait.
- Pulsing Blue: Deco is ready for setup.


DECO'S LED IS PULSING BLUE

[Why is my LED not pulsing blue?](#)


11. Tap on join




12. This screen will show once your phone/tablet is connected over WiFi to the Deco X58-4G




13. Enter a Network Name and password to create your Deco WiFi Network, then tap on NEXT

A light teal screen with a white 'X' in the top left corner. The title "Create your Wi-Fi Network" is at the top. Below it is a paragraph: "This will be the name and password you'll use to access your network. Your password must be at least 8 characters." There are two input fields: "Network Name" and "Password". Below the fields is a paragraph: "It is recommended to set a password using a combination of letters, numbers, and symbols." At the bottom is a grey rounded button labeled "NEXT". The text "Now, let's create your Wi-Fi network." is at the very bottom.


14. This screen will show when your Deco WiFi Network is being created




15. Tap on **CONNECT** to connect your phone/tablet to your new Deco WiFi network



16. This screen will show once your phone /tablet is connected




17. If your phone/tablet fails to connect this screen will be shown. Tap on **TRY AGAIN** to attempt connecting again



[Still having problems?](#)

18. This screen will show to confirm your X58-4G is now online



19. Setup of the X58-4G is complete. Tap DONE to finish

Your Deco network is now up

Your Deco is ready to use. Please connect all devices to the Deco network for better connections.



ADD ANOTHER DECO

DONE

20. The main screen of the Deco App will look like this once you have completed Setup

