1. Connect to the modem via Wire or Wireless
2. Open a Browser (Chrome, Firefox, etc.) and enter **192.168.20.1** in the address bar
3. Enter **admin** as both the Username and the Password
4. Using the left-hand panel, navigate to Advanced Setup > WAN Service and click Add

5. Select **ptm0/(0_1_1)** from the dropdown the click Next

6. Make sure the following settings are in place and then click Next

7. Make sure the following settings are in place then click **Next**

8. Continue clicking Next until reaching this page, then click Apply/Save

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP.

Connection Type:	PPPoE
NAT:	Enabled
Full Cone NAT:	Disabled
Firewall:	Enabled
IGMP Multicast:	Disabled
Quality Of Service:	Disabled

Click "Apply/Save" to have this interface to be effective. Click "Back" to make any modifications.

Back   Apply/Save