1. Connect to the modem via wire or wireless
2. Open a browser (Chrome, Firefox, Safari, etc.) and enter **192.168.20.1** in the address bar
3. Enter **admin** as the username and find the password on the bottom of your modem
4. On the left-hand side, click **Basic Setup**



5. Select **VDSL** and then click **Next**



6. Select **PPP Over Ethernet (PPPoE)** and then click **Nex**



7. Select **VLAN Tag 10 (For most New Zealand customers)** and click **Next**



8. Match the following details and then click **Next**



9. Click **Apply/Save**